



REF	PART #	DESCRIPTION
1	PN36	HEX NUT 1-1/4"-7 (RH THREAD)
2	P0530002	SPACER 1-1/4" ID x 1-3/4" OD x 1-1/2" L
3	P0530003	SPEED CONTROL
4	P0530004	EMERGENCY STOP SWITCH
5	P0530005	STOP SWITCH
6	P0530006	START SWITCH
7	P0530007	TACHOMETER
8	P0530008	JUNCTION BLOCK
9	P0530009	FUSE 3A
10	P0530010	CONTACTOR
11	P0530011	SAFETY SWITCH
12	P0530012	FREQUENCY CONVERTER
13	P0530013	CONTROL BOX HOUSING
14	PB86	HEX BOLT 5/16-18 X 3/4"
15	P0530015	CONTROL BOX SWITCH SUPPORT
16	PFH02M	FLAT HD SCR M6-1 X 12
17	PB86	HEX BOLT 5/16-18 X 3/4"
18	PWR1-1/2	WRENCH 1-1/2"

REF	PART #	DESCRIPTION
19	PWR2	WRENCH 2"
20	PN37	HEX NUT 1-1/4" -7 (LH THREAD)
21	P0530021	MOTOR 5-HP 3-PHASE
27	P6209	MOTOR BEARING 6209ZZ
28	P0530028	WARNING LABEL
29	PLABEL-37	RESPIRATOR LABEL
30	PLABEL-11	SAFETY GLASSES LABEL
31	G9987	GRIZZLY LOGO 4-3/4" X 2-1/4"
32	P0530032	DOOR
33	P0530033	SPACER 1-1/4" ID x 1-3/4" OD x 2" L
34	P0530034	SPACER 1-1/4" ID x 1-3/4" OD x 1" L
35	P0530035	FUSE HOUSING
36	P0530036	MAIN PWR CORD 12-GA 3-PH 220V
37	P0530037	MTR PWR CORD 12-GA 3-PH 220V
38	PLABEL-14	ELECTRICITY LABEL
39	PLABEL-36	UNPLUG 220V LABEL
40	P0530040	CONTROL PANEL DATA/ID LABEL