



REF	PART #	DESCRIPTION
701	PSB48M	CAP SCREW M6-1.0 X 35
702	PH5749702	LASER CLAMP ASSEMBLY
702-1	PH5749702-1	LASER CLAMP (TOP)
702-2	PH5749702-2	LASER CLAMP (BOTTOM)
703	PH5749703	LASER
704	PSB01M	CAP SCREW M6-1.0 X 16
705	PH5749705	LASER BRACKET ASSEMBLY
705-1	PSB18M	CAP SCREW M4-0.7 X 8
705-2	PW05M	FLAT WASHER 4MM
705-3	PH5749705-3	LASER BRACKET (TOP)

REF	PART #	DESCRIPTION
705-4	PH5749705-4	LASER BRACKET (BOTTOM)
706	PH5749706	STEEL ARM
707	PSB31M	CAP SCREW M8-1.25 X 25
708	PS05M	PHLP HD SCR M5-0.8 X 8
709	PH5749709	POWER BOX
710	PH5749710	FUSE T1AL250V
711	PH5749711	FUSE COVER
712	PLW04M	LOCK WASHER 8MM
713	PW01M	FLAT WASHER 8MM
714	PW03M	FLAT WASHER 6MM

COPYRIGHT © NOVEMBER 2003 BY GRIZZLY INDUSTRIAL, INC.
WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.
 #5902 PRINTED IN TAIWAN